# PC190 Quick Start Guide

### **Lumens**

## Important

- \* Please activate your warranty at www.lumens.com.tw/reg
- \* Please visit our website <a href="www.lumens.com.tw/goto.htm">www.lumens.com.tw/goto.htm</a> to download latest version of Software, Multilingual User Manual and Quick Start Guide.

### 1. Package Contents

PC190



**Quick Start** 



\* To download this manual in other languages, visit Lumens website

Guide




& Safety

**Download** Instruction



Remote Control



**USB Cable** 

**VGA Cable** 

**Audio Cable** 

**Power Cord** 

4-Step Card

Remote **Control Holder** 









in different countries



**Accessory Pouch** 




**Pouch** 



Microscope Adapter






### 2. Getting Started




- Place an object to be displayed under the camera.
- (2) Turn the power on.
- (3) Adjust the gooseneck and lens to appropriate position.
- (4) Press the [ AUTO TUNE ] button to optimize the image. You are ready to teach / present.
  - \* Each time the camera head is moved, press the [FOCUS] button to refocus the lens.




## 3. Installation & Connection



#### **▼** Connect to a Projector or Monitor




# **▼** Connect to a Computer and Use Podium View<sup>™</sup> Software




\* Driver and software can be downloaded from Lumens website.

# **▼** Connect a Computer, Projector or Monitor simultaneously




\* Press [ SOURCE ] button to switch the image source.

#### ▼ Connect to an Interactive Whiteboard (IWB)



#### **▼** Connect to a TV



\* NTSC: USA, CANADA, MEXICO, PANAMA, CHILE, JAPAN, TAIWAN, KOREA AND PHILIPPINES.

- \* PAL: Country / region not listed above.
- ★ To make DIP switch set up effectiveness, please re-plug the power cord and reboot the machine. Once C-Video is on, VGA is not supported.

#### **▼** Connect to a Computer and Flash Disk

